





MINIMAT-EC-Servo Screwdriver Spindles

Maximum Flexibility and Process Control

Straight Spindle Form - Torque range from 0.2 Nm - 350 Nm

- powerful
- flexible
- high precision
- full documentation capability

MINIMAT-EC-Servo screwdriver spindles in connection with the sequence controller AST40 allow free programming of the screw tightening process and offer maximum flexibility, accuracy and process control.

Torque, speed, angle, drive direction and sequence delay times can be customized to the individual screwdriving task within the power range of the selected screwdriver spindle.

The integrated torque and angle sensor module employs non contact signal transmission techniques and enables precise control of the screwdriving process as well as the documentation of the screwdriving results and process parameters and also guarantees the highest shut-off accuracy. The EC-Servo screwdriver is suitable for applications with the most demanding quality requirements – where direct measurement and control methods are required.



ADVANTAGES

- High power density
- · High shut-off accuracy
- Flexible
- Noise immunity
- Comprehensive documentation options
- · System diagnostics
- Extensive integration and control options

The application of a brushless servomotor with high power density is essential to the maintenance free operation of the EC drive. It also delivers excellent dynamics and high peak torque in a compact form – ideally suited to the screw tightening process.

The DEPRAG screwdrivers based on EC technology enable a torque accuracy of < 1% standard deviation, which can be relied upon after millions of cycles.


Thus, a Cmk value of \geq 1.67 with a tolerance requirement of \pm 5% in reference to 6 Sigma is reached.

A Cmk value of 1.67 means that the error rate is less than 0.6 per one million screw assemblies.

The screwdriving system consists of the EC screwdriver spindle, AST40 screwdriver sequence controller and a single connection cable that has been tested for extreme loading conditions. The single connection cable services the power and signal transmission functions between the screwdriver and controller using digital technology as most suitable for longer cable lengths.

Extensive programming, control and documentation interfaces offer maximum flexibility for integration into existing process environments. Several communication options include input/output, various field bus interface options, a 7" touch panel and an integrated web server for online screwdriver program configuration, data backup and screwdriver graph analysis via Ethernet. All common screw assembly sequence programs are embedded in the AST40 screwdriver controller in the form of commands with parameters. Commissioning of an application can be completed in just a few steps. All required programming and setup functions are made available through the web interface so that no additional software is required, only a PC with a browser.

SYSTEM OVERVIEW



| MINIMAT-EC-Servo, straight spindle form | | size 27 with quick change chuck | | | |
|--|----------------------|---------------------------------|-------------------------------|-------------------------------|-------------------------------|
| Screwdriver | Type Part no. | 311E27-0010 413400A | 311E27-0020 413400B | 311E27-0050 413400C | 311E27-0120 413400E |
| Torque min. | Nm / in.lbs | 0.2 / 1.77 | 0.4 / 3.54 | 1 / 8.85 | 2.4 / 21.24 |
| Torque max. | Nm / in.lbs | 1 / 8.85 | 2 / 17.7 | 5 / 44.25 | 12 / 106.2 |
| Speed min. | rpm | 100 | 60 | 40 | 20 |
| Speed max. | rpm | 1600 | 1500 | 800 | 400 |
| Diameter | mm / in. | 27 / 1.05 | 27 / 1.05 | 27 / 1.05 | 27 / 1.05 |
| Length | mm / in. | 360 / 14.05 | 360 / 14.05 | 360 / 14.05 | 360 / 14.05 |
| Weight | kg / lbs | 1.2 / 2.64 | 1.2 / 2.64 | 1.2 / 2.64 | 1.2 / 2.64 |
| Noise level | dB(A) | 60 | 60 | 60 | 60 |
| Internal hex. drive DIN ISO 1173 | | F6.3 | F6.3 | F6.3 | F6.3 |
| Suitable tool inserts and connecting components with a drive as per DIN ISO 1173 | | E6.3 | E6.3 | E6.3 | E6.3 |

MINIMAT-EC-Servo, straight spindle form

size 36 with quick change chuck

| Screwdriver with quick change chuck | Type Part no. | 311E36-0150 205000A | 311E36-0300 205000C | 311E36-0500 205000D |
|--|-------------------------|-------------------------------|-------------------------------|-------------------------------|
| Torque min. | Nm / in.lbs | 3 / 26.55 | 6 / 53.1 | 10 / 88.5 |
| Torque max. | Nm / in.lbs | 15 / 132.75 *) | 30 / 265.5 *) | 50 / 442.5 *) |
| Speed min. | rpm | 50 | 30 | 20 |
| Speed max. | rpm | 1000 | 600 | 380 |
| Diameter | mm / in. | 36 / 1.4 | 36 / 1.4 | 36 / 1.4 |
| Length | mm / in. | 476 / 18.56 | 476 / 18.56 | 476 / 18.56 |
| Weight | kg / lbs | 2.8 / 6.2 | 2.8 / 6.2 | 2.8 / 6.2 |
| Noise level | dB(A) | 60 | 60 | 60 |
| Internal hex. drive DIN ISO 1173 | | F6.3 | F11.2 | F11.2 |
| Suitable tool inserts and connecting components with a drive as per DIN ISO 1173 | | E6.3 | E11.2 | E11.2 |

| MINIMAT-EC-Servo, straight spindle form | | size 42 with | quick change chuck | size 63 | |
|---|-------------------------|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| Screwdriver with quick change chuck | Type Part no. | 311E42-0300 206000B | 311E42-0800 206000D | 311E63-1800 416400D | 311E63-3500 416400F |
| Torque min. | Nm / in.lbs | 6 / 53.1 | 16 / 141.6 | 36 / 318.6 | 70 / 619.5 |
| Torque max. | Nm / in.lbs | 30 / 265.5 | 80 / 708 | 180 / 1593 | 350 / 3097.5 |
| Speed min. | rpm | 50 | 20 | 15 | 10 |
| Speed max. | rpm | 890 | 330 | 300 | 155 |
| Diameter | mm / in. | 42 / 1.64 | 42 / 1.64 | 63 / 2.46 | 63 / 2.46 |
| Length | mm / in. | 478 / 18.64 | 478 / 18.64 | 617 / 24.06 | 617 / 24.06 |
| Weight | kg / lbs | 4.2 / 9.24 | 4.2 / 9.24 | 12.9 / 28.38 | 12.9 / 28.38 |
| Noise level | dB(A) | 60 | 60 | 62 | 62 |
| Internal hex. drive DIN ISO 1173 | | F11.2 | F11.2 | - | - |
| External square drive DIN 3121 | | - | - | F20 (3/4") | F20 (3/4") |
| Suitable tool inserts and connecting components with a drive as per DIN ISO 1173 with a drive as per DIN 3121 | | E11.2 | E11.2 | - H20 (3/4") | - H20 (3/4") |

^{*)} With a voltage below 180V the maximum torque will be reduced to 80% of the specified value.

Optional Accessories

| Machine Capability Study Torque *) | Part no. | 000717 | - Evaluation of 50 measured values |
|--|----------|--------|--|
| Machine Capability Study Torque angle *) | Part no. | 000718 | - Idle speed, Average - Standard deviation, Cm-Value, Cmk-Value |

^{*)} Additional services, e.g. calibration of screwdrivers, can be found in our catalog D3330 E.

Motor Cable

| Length | Part no. |
|------------------------|----------|
| 5 m/16.4 ft (standard) | 8337252 |
| 8 m/26.2 ft | 8337253 |
| 12 m/39.4 ft | 8337254 |

The screwdriver spindles size 27 and type 311E36-0150 (size 36) can also be delivered with an automatic screw feed system. Please contact us for more information!



| ST40 | | 311E27/36/42 | 311E63 |
|---|----------|---------------|-----------------------|
| Sequence controller | Туре | AST40-1 | AST40-2 |
| Basic version with input/output interface | Part no. | 385588A | 387022A |
| Sequence controller | Туре | AST40-1 PB | AST40-2 PB |
| with fieldbus module Profibus port | Part no. | 385588B | 387022B |
| Sequence controller | Туре | AST40-1 PN | AST40-2 PN |
| with fieldbus module Profinet port | Part no. | 385588C | 387022C |
| Sequence controller | Туре | AST40-1 EC | AST40-2 EC |
| with fieldbus module EtherCat port | Part no. | 385588D | 387022D |
| Sequence controller | Туре | AST40-1 E/IP | AST40-2 E/IP |
| with fieldbus module Ethernet IP port | Part no. | 385588E | 387022E |
| Sequence controller | Туре | AST40-1 RS232 | AST40-2 RS232 |
| with interface AST40 RS232 | Part no. | 385588F | 387022F |
| for data output, format programmable via | web page | | |
| Power unit (AC) | V | 1 | 00 - 240 |
| | Hz | , | 50 / 60 |
| Insulation | | | IP54 |
| TFT-display (touch) | | 7", | 800x480 |
| 24V input/output interface | | | ts / 30 outputs |
| Dimensions (W x H x D) | mm / in. | 232 x 315 x 2 | 205 / 9.05 x 12.3 x 8 |
| Weight | kg / lbs | 7 | .5 / 16.5 |

for screwdriver

for screwdriver

The sequence controller AST40 is a controller with integrated power supply. Within the performance range of each spindle torque, speed, waiting period and rotational direction can be individually customized to the screw assembly task.

Extensive programming, control and documentation interfaces offer maximum flexibility for integration into existing process environments. Several communication options include input/output, various field bus interface options and an integrated web server for online screwdriver program configuration, data backup and screwdriver graph analysis via Ethernet.

All common screw assembly sequence programs are embedded in the AST40 screwdriver controller in the form of commands with parameters. Commissioning of an application can be completed in just a few steps. All required programming and setup functions are made available through the web interface so that no additional software is required, only a PC with a browser.

Required Accessories

| Power supply cable | Length 1.8 m/5.9 ft | (EU) | Part no. | 385443A |
|--------------------|---------------------|----------|----------|---------|
| Power supply cable | Length 1.8 m/5.9 ft | (USA) | Part no. | 385443B |
| Power supply cable | Length 1.8 m/5.9 ft | (Brazil) | Part no. | 385443D |
| Power supply cable | Length 2.5 m/8.2 ft | (China) | Part no. | 385443C |

Optional Accessories



| Interface Graph Loader (hardware and software) | Part no. | 385834A |
|--|----------|---------|
| Connection cable (AST40 - Graph Loader) | Part no. | 385835D |

The storage of screwdriving graphs and end value data sets (e.g. torque, angle etc.) for manual work stations and screwdriving stations can be carried out automatically using the Interface Graph-Loader. The corresponding software enables immediate display on the computer screen of the current screwdriving graph, the screw assembly can be evaluated straight after completion and *csv and *bin files can be saved in individual directories.



| Software ASTxx Serial Remote (release code) | | | |
|---|----------|--------|--|
| for the simple storage of screwdriving curves and | Part no. | 206565 | |
| result-data to a PC | | | |

The program ASTxx Serial Remote is started on a PC and is controlled by commands over a serial interface (COM-Port). With this program, screwdriving curves and result-data can be transferred fast and simply onto a PC. The PLC controls when and which data should be stored. The storage place (also the directory) on the PC is determined by the PLC as well. The directory is setup automatically on the PC.

| Sequence Controller ASTi40 | | for screwdriver 311E27/36/42 | for screwdriver 311E63 | |
|---|----------|---------------------------------|---------------------------|--|
| Sequence controller | Туре | ASTi40-1 | ASTi40-2 | |
| Basic version with input/output interface | Part no. | 428006A | 387044A | |
| Sequence controller | Туре | ASTi40-1 PB | ASTi40-2 PB | |
| with fieldbus module Profibus port | Part no. | 428006B | 387044B | |
| Sequence controller | Туре | ASTi40-1 PN | ASTi40-2 PN | |
| with fieldbus module Profinet port | Part no. | 428006C | 387044C | |
| Sequence controller | Туре | ASTi40-1 EC | ASTi40-2 EC | |
| with fieldbus module EtherCat port | Part no. | 428006D | 387044D | |
| Sequence controller | Туре | ASTi40-1 E/IP | ASTi40-2 E/IP | |
| with fieldbus module Ethernet IP port | Part no. | 428006E | 387044E | |
| Sequence controller | Туре | ASTi40-1 RS232 | ASTi40-2 RS232 | |
| with interface AST40 RS232 | Part no. | 428006F | 387044F | |
| for data output, format programmable via | web page | | | |
| Power unit (AC) | V | 100 | - 240 | |
| | Hz | 50 / 60 | | |
| Insulation | | IP54 | | |
| 24V input/output interface | | 27 inputs | / 30 outputs | |
| Dimensions (W x H x D) | mm / in. | 232 x 315 x 20 | 5 / 9.05 x 12.3 x 8 | |
| Weight | kg / lbs | 7.5 / | 16.5 | |



for installation into a switch cabinet

The sequence controller AST40 is a controller with integrated power supply. Within the performance range of each spindle torque, speed, waiting period and rotational direction can be individually customized to the screw assembly task.

Extensive programming, control and documentation interfaces offer maximum flexibility for integration into existing process environments. Several communication options include input/output, various field bus interface options and an integrated web server for online screwdriver program configuration, data backup and screwdriver graph analysis via Ethernet.

All common screw assembly sequence programs are embedded in the AST40 screwdriver controller in the form of commands with parameters. Commissioning of an application can be completed in just a few steps. All required programming and setup functions are made available through the web interface so that no additional software is required, only a PC with a browser.

Included in delivery

| ASTi40 reset plug | Part no. | 425080A |
|--|----------|---------|
| Patch cable (connection cable ASTi40 - PC) | Part no. | 831902 |

Required Accessories

| Power supply cable | Length 1.8 m/5.9 ft | (EU) | Part no. | 385443A |
|--------------------|---------------------|----------|----------|---------|
| Power supply cable | Length 1.8 m/5.9 ft | (USA) | Part no. | 385443B |
| Power supply cable | Length 1.8 m/5.9 ft | (Brazil) | Part no. | 385443D |
| Power supply cable | Length 2.5 m/8.2 ft | (China) | Part no. | 385443C |

Optional Accessories

| Interface Graph Loader (hardware and software) | Part no. | 385834A | |
|--|----------|---------|--|
| Connection cable (AST40 - Graph Loader)) | Part no. | 385835D | |

The storage of screwdriving graphs and end value data sets (e.g. torque, angle etc.) for manual work stations and screwdriving stations can be carried out automatically using the Interface Graph-Loader. The corresponding software enables immediate display on the computer screen of the current screwdriving graph, the screw assembly can be evaluated straight after completion and *csv and *bin files can be saved in individual directories



| Software ASTxx Serial Remote (release code) | ' | | |
|---|----------|--------|--|
| for the simple storage of screwdriving curves and | Part no. | 206565 | |
| result-data to a PC | | | |


The program ASTxx Serial Remote is started on a PC and is controlled by commands over a serial interface (COM-Port). With this program, screwdriving curves and result-data can be transferred fast and simply onto a PC. The PLC controls when and which data should be stored. The storage place (also the directory) on the PC is determined by the PLC as well. The directory is setup automatically on the PC.



Optional Equipment

| For sequence controller | Туре | AST40 | ASTi40 | |
|---|----------|--------|--------|--------|
| Software Friction value screwdriving (release code) | Part no. | 201820 | 201820 | Torque |

With the friction-value process, it is possible to measure and compensate varying friction-values (e.g. on self-forming screw-joints). Additionally, this procedure can be used for monitoring of predetermined friction values at verification processes.



| Software Datalogger (| (release code) | Part no. | 202699 | 202699 |
|-----------------------|----------------|----------|--------|--------|
|-----------------------|----------------|----------|--------|--------|

The software "Datalogger" offers the possibility to record and archive the final-values of up to 10 sequence controllers. This storage format corresponds with the required format of the software "Statistics", so that the data sets can be analyzed with the software "Statistics". It can be selected whether the data is collected automatically while the program is running, or whether the data reading should be triggered manually. The connection to the controllers is done by Ethernet and TCP/IP. The software is available in several different languages.



| Software Statistics (release code) Part no. 206081 20608 |
|--|
|--|

The software "Statistics" offers the possibility to produce statistical evaluations for the screwdriving results, that are made available by the software "Datalogger". In order to be able to use the software "Statistics", the software "Datalogger" must be installed as well!



| Software GRAPH10 | Part no. | - | 832380 |
|------------------|----------|---------|--|
| | | | The software GRAPH10 enables display on the computer screen of the screwdriving graph. |
| Software DAST100 | Part no. | - | 815641 |
| Software DAST200 | Part no. | - | 815642 |
| | | | The software-panel for EC and EC Servo Systems. DAST is used to supervise the operation and visualisation of the screwdriver sequence controller (AST series) through the system control. |
| Table stand | Part no. | 300085A | - |
| Patch cable 2 m | Part no. | 831902 | _ |
| Touch pen | Part no. | 832190 | _ |

Handle with quick change chuck

| For EC-Servo screwdriver spi | indles | 311E27-xxxx | 311E36-0150 | 311E36-0300 311E36-0500 |
|----------------------------------|----------|-------------|-------------|----------------------------|
| Handle | Part no. | 425800A | 425900A | 425900B |
| Internal hex. drive DIN ISO 1173 | | F6.3 | F6.3 | F11.2 |

Handle with vacuum connection

| For EC-Servo screwdriver spin- | dles | 311E27-xxxx | 311E36-0150 | 311E36-0300 311E36-0500 |
|----------------------------------|----------|-------------|-------------|----------------------------|
| Handle | Part no. | 425800E | 425900F | 425900G |
| Internal hex. drive DIN ISO 1173 | | F6.3 | F6.3 | F11.2 |

Handle with integrated mouthpiece guide

for the use in connection with an automatic screw feeder

| For EC-Servo screwdriver spindles | 311E27-xxxx | 311E36-0150 |
|--|-------------|-------------|
| Handle, Length of stroke 80 mm Part no. | 4258001B | 425900C |
| Handle, Length of stroke 100 mm Part no. | 4258001C | 425900D |
| Handle, Length of stroke 120 mm Part no. | 4258001D | 425900E |

The handle has an LED status display (OK/NOT OK), an ergonomic start lever and an additional button for reversal or to start a screwdriving program.

Operating elements can be adapted to a specific application by selecting the operat-ing mode. In this way for example the tool can be pre-programmed so that a second screwdriving program can be started directly by pressing the switch (e.g. a loosening program).

Alternatively the mode can be selected so that the button is used for the pre-selection of the screwdriving program started via lever.



Required Accessories

| For EC-Servo screwdriver spindles | | 311E27-xxxx | 311E36-xxxx |
|---|-----------|-------------|-------------|
| Screwdriver adapter for the attachment to a linear stand (suitable for all handle variants) | Part. no. | 4008333C | 4008333B |
| Connection cable to AST40 | Part. no. | 385584A | 385584A |
| Connection cable to PLC | Part. no | 385584B | 385584B |

The suitable linear stands and balancers can be found in our brochure D3345E.

Optional Accessories

| For EC-Servo screwdriver sp | indles | 311E27-xxxx | 311E36-xxxx |
|-----------------------------|----------|-------------|-------------|
| Turn fixture | Part no. | 917333A | on request |

The rotary unit is integrated between the screwdriver adaptor and handle and enables rotation of the handle. Ergonomic handling is therefore guaranteed even on larger work surfaces.

Please note: When using the rotary unit with the version of the handle with quick change chuck or vacuum connection the holder on the handle must be replaced by the holder part number 917695 which must be ordered separately.

| Support ring | Part no. | 398704A | 398704A | | |
|--|----------|---------|---------|--|--|
| The support ring can not be used in connection with handle with integrated mouthpiece guide. | | | | | |







